

SJOPEK

Future Pet Food Conference 2024

Innovations in Pet Food Packaging Focus on Sustainability and Cost Efficiency

MULTIVAC SLIDPRCK

About Us

SUDPACK



Matthias Schrägle VP R&D Group Südpack





Klaus Deniffel Corporate Product Manager MULTIVAC



Agenda



© MULTIVAC · 2023



About

Solutions by MULTIVAC

MULTIVAC SUDPACK

Solutions by MULTIVAC



Topic of the presentation

Sterilized Wet Pet Food: Market Entry Strategy MULTIVAC

Option 1: **New Processing & Packaging Method** Continuous direct steam injection heating, followed by hot filling and packaging Partners **MULTIVAC** natec NFTWOR handtmann Ideen mit Zukunft

Option 2: **New Packaging Method** Use of a thermoformed flexible film packaging, sterilized in an autoclave **Partners** SUDPACK



Vision | Our new way of

Packaging Wet Pet Food



Our Vision: Rethinking Packaging for Wet Pet Food


Our target scope ...



... with concepts that enable sterilization and meet retail & customer requirements.


MULTIVAC SUDPACK

Our Concept: New Solution for Sterilized Wet Pet Food



MULTIVAC SUDPACK

Stronger Together: Selecting the Right Partner





Innovation

Film Development 1.0



Development

Film Development 1.0

Main Targets for the Development of a Retortable and Thermoformable Film:

Withstand Retort Process:

oCapable of enduring temperatures up to 128°C for 45 minutes.

• Thermoformable Film:

•Ensuring the film can be easily thermoformed.

• OTR Barrier:

•Maintaining an oxygen transmission rate (OTR) barrier below 1 after the retort process.

Reduced Whitening Effect:

oMinimizing the whitening effect post-retort.

Film Development 1.0

Materials for thermoforming

Material	Function	Under retort
PA	High elongation and stress resistance	water absorption
EVOH	Flexible, Barrier OTR	retort shock
PE	Thermical Sealablility	melting @ 100°C

Material	Function
PA	low water absorption and good elongation; low re-shrinkage
EVOH	Maintains OTR under retort conditions and high humidity
PP	Good formability and temperature resistance >135°C; high sealing force


Materials for retort

Material	Function	Under thermoforming
Alu / AlOx / SiOx	Barrier	Break – loos of barrier
PP	Thermical Sealablility	limited available resins

During sterilization at e.g.128° C, EVOH can experience "retort shock." The barrier properties significantly decrease due to high temperature and humidity.

MULTIVAC SUDPACK

Film Development 1.0



Based on the selection and positioning of EVOH and PA in the development film, laboratory tests demonstrated an oxygen transmission rate (OTR) barrier of approximately 1 ccm/m² x d x bar


This performance was significantly better compared to a standard film.

Inclusion of Pet Food Manufacturers

Customer-centered development

Customer Austria

- Medium-sized family business in its 4th generation
- Specializing in meat products
- Pet food for several years



Customer Switzerland

- Internationally active group
- Equally specialized in human and pet food
- In the top 20 in Europe for pet food



Sterilization Test: Customer Austria

Package:

- thermoformed flex film vacuum package
- 250 μm bottom film | 125 μm upper film

Autoclaving process :

• Temperature:	121 °C
• Bar:	2,4 bar
• Time:	1:40 h

Result

- Still perfectly sealed packages
- No evidence of material degradation
- No visible degradation of the pet food



Sterilization Test: Customer Switzerland

Package:

- thermoformed flex film vacuum package
- 250 μm bottom film | 125 μm upper film

Autoclaving process :

• Temperature:	129 °C
• Bar:	3,2 bar
• Time:	1:42 h

Result

- Some packages have burst open at the sealed seam. Reason: too much residual oxygen.
- Packages with little residual oxygen are flawless.







Innovation

Film Development 2.0



Development

Film Development 2.0

Tighter Sealing of the Packaging:

• Enhanced sealing capabilities have been achieved.

Modification of PP Resin Selection:

• Slight adjustments have been made to the polypropylene resin selection.

•Recyclable solution

• Our PA-free version currently withstands the pasteurization process. Further development is underway to achieve compatibility with the retort process

Sterilization Test: Customer Austria

Package:

- thermoformed flex film vacuum package
- sterilization: 250 µm bottom film | 125 µm upper film
- pasteurisation: 150 µm bottom film | 75 µm upper film

Autoclaving process :		process :	Pasteuriza
	Temperature:	121 °C	Temperatu
	Pressure:	2,4 bar	Pressure:
	Time:	1:40 h	Time:

Pasteurization process:

nperature:	85 °C
ssure:	1,0 bar
e:	1:28 h

Result

- Still perfectly sealed packages
- No evidence of material degradation



Sterilisation



Pasteurisation



Sterilization Test: Customer Switzerland

Package:

- thermoformed flex film vacuum package
- 250 μm bottom film | 125 μm upper film

Autoclaving process :

• Temperature:	129 °C
• Bar:	3,2 bar
• Time:	1:42 h

Result

- Slight discoloration of the film, otherwise no change
- Very low residual oxygen content







Innovation Creation

Comparison with existing Packaging Concepts





Development

Sustainability




Basis for• Recommended daily feed quantity for a 10 kg dog*Comparison \rightarrow 400g/day (=functional Unit)





Sustainability









Simplified Handling







Database 240 Pack/min x 60 min x 16 h x 70% availability x 250 days = 40.320.000 Packs/Year




Cans || 161.280 : 1760 Cans/Palette = 92 Pallets/Day | 40.320.000 Packs/Year : 1760 Packs/Pallett : 68 Pallets/Truck = 337 Tucks/Year Database Our Packs – Bottom Film || 161280 Packs/day : 4 rows x 0,105 cm/Pack : 0,9 film use : 270 m/roll : 24 rolls/pallet = 0,73 pallets/day | 4,12 Truck/Year Our Packs – Upper Film || 161280 Packs/day : 4 rows x 0,105 cm/Pack : 0,9 film use : 500 m/roll : 24 rolls/pallet = 0,39 pallets/day | 2,22 Tucks/Year







Cans|| 1760 cans/pallet x 0,465 kg/can + 22 kg/pallet = 840,4 kg/pallet | 31t : 840,4 = 36 Pallets/Truck | 36 Pallets/Truck x 1760 Packs/Pallet = 63.360 Packs/TruckDatabaseOur Packs || 2592 packs/pallet x 0,410 kg/pack + 22 kg/pallet = 1082,72 kg/pallett | 31t: 1082,72 = 28 Pallets/Truck | 28 x 2592 packs/pallet = 72.576 Packs/Truck





Opening aids

Greater Packaging Individuality

Some of the possibilities

- ✓ Packing geometry & size
- ✓ Film type & thickness
- ✓ Opening aids, perforation, embossing
- ✓ Individual printing & labeling

Suitable for the Digital Product Passport R-Cycle

Flexible dimensions

MULTIVAC SUDPACK

Perforation



Cost efficiency





Our Vision: Rethinking Packaging for Wet Pet Food

Our target scope ...



... with concepts that enable sterilization and meet retail & consumer requirements.



Futher Goals

What's next?



Future Goals

MULTIVAC SUDPACK

Further Goals | What's next?



MULTIVAC SUDPACK

Interested? Get in touch with us!

SUDPACK



Matthias Schrägle VP R&D Group Südpack





Klaus Deniffel Corporate Product Manager MULTIVAC Future Pet Food Conference 2024

Innovations in Pet Food Packaging Focus on Sustainability and Cost Efficiency

MULTIVAC SLIDPACK



SJOPEK